

A view from inside the outside pen looking at the trap door that can be shut or opened by an outside rope. The clear window can be shut up for winter or to close off the draft. The window can be opened and the opening has a wire covering.



All chicken houses have a rope to pull the chicken house to a new grassy area. The front door of the outside pen also has a small door that can be opened to let your chickens free range (free ranged chickens).



Another view showing the rope to pull the chicken houses.




A left view from the door of the chicken house. Left side you will find the egg nest box and roost pole for the chickens, solid enclosed floor, insulated ceiling, trap door to the outside pen, a front and back clear windows.



A right side view from the door of the chicken house. Right side you will find a roost pole for the chickens, solid enclosed floor, insulated ceiling, trap door to the outside pen and window view to the outside enclosed run pen.



A view of the hinged clear plastic window on the door of the chicken house.



A two hole nest box comes with the #1 chicken house. An outside door unlatches from the nest box for easy access of gathering chicken eggs from the outside of the chicken house.



A three hole nest box comes with the #2 chicken house. An outside door unlatches from the nest box for easy access of gathering chicken eggs from the outside of the chicken house.



Automatic water in outside pen



Automatic Feeder inside door



Roosting Poles Inside House

